



## Sugar cane pulp

- Extract molecules (DNA, RNA, protein, chemicals)
- Wet final product
- Sample sizes: up to 300 mg.

**Notes on the protocol:** This protocol does not specify a particular buffer - you may choose which is most appropriate for your downstream application (nucleic acid isolation, protein extraction, etc.).

### Materials Required

One of these Bullet Blenders

- **Bullet Blender** (BBX24)
- **Bullet Blender Blue** (BBX24B)
- **Bullet Blender Storm 24** (BBY24M)
- **Bullet Blender 24 Gold** (BB24-AU)

Reagents

#### Homogenization buffer

2 x volume of sample

#### PBS (optional)

3 x volume of sample

Bead choices

- **GREEN bead lysis kit** (GREEN) (for samples up to 100 mg.)
- **NAVY bead lysis kit** (NAVY) (for samples between 100 and 300 mg.)
- **0.9 - 2.0 mm stainless steel blend** (SSB14B) Use a volume of beads equivalent to 1 x the volume of the sample

### Procedure

1. Cut the sample into appropriately sized pieces. For larger samples, we recommend cutting the material into long, thin strips for faster homogenization.
2. (Optional) Wash the sample 3x with 1/2 tube volume of PBS to remove surface contaminants.
3. Place the sample in the tube with the beads.
4. Add a volume of buffer that is twice the volume of the sample. Sample volume may be approximated by sample weight. E.g., for a 100 mg. sample, add 0.2 ml. buffer.
5. Close the tubes tightly and place them in the Bullet Blender.
6. Set the controls for Speed 10 and Time 4. Press Start.
7. After the run, remove the tubes from the instrument and visually inspect the samples. If homogenization is incomplete, repeat the homogenization step at a higher speed.
8. Proceed with your downstream application.